



RoamingSIM Data SIM Start-Up

Before you can use your RoamingSIM DATA SIM you must follow these steps:

1. Register your SIM at: www.roamingsim.com.au
2. Insert your SIM into your unlocked mobile phone or unlocked modem
3. Enter your PIN number **0000**
4. Change your Access Point Name (APN) settings:
 - Access Point Name : **speedidata.com**
 - Username: **speedidata**
 - Password: **speedidata**

RoamingSIM DATA SIM's are compatible with any unlocked mobile phone or modem. For successful setup you must change your Access Point Name (APN) Settings. This will allow your RoamingSIM DATA SIM to connect to a network. The location for this information will vary depending on the device you are using so please see your phone or modem manual for further information.

Note: If you use a different SIM in your mobile phone or modem you will have to change your APN setting every time you use your RoamingSIM DATA SIM again.

Adding Credit:

You can add credit to your personal online account at www.roamingsim.com.au

Useful Tips:

- If you have trouble connecting to a network first check that you have sufficient credit
- Make sure you have network coverage
- Manually search for another network, see the preferred carrier in the coverage page at www.roamingsim.com.au

24/7 Customer Support:

UK: +44-20-80997266

Ireland: +353-21-4521907

USA: +1-415-829-5219

Australia: +61-3-9001-5540

Hong Kong: 800-964-168 (toll free)

Email: support@roamingsim.com.au